



# Single Axis Robots RSDG2 - Rod Type with Support Guide



CE Compliant

See notes on CE Marking. P.49

CAD Data Folder Name: 07\_Actuator

When placing order, select part numbers and values by proceeding through Selection Steps ①~⑦.

Ordering Example	Part Number (Type, ① Lead, ② With or w/o Brake)	③ Motor Mounting Direction	④ Controller	⑤ I/O Module	⑥ Cable Length	⑦ Stroke	
	RSDG206B	U	C1	N	3	200	(Motor Mounting Direction: U)
	RSDG206B		C1	N	3	200	(Motor Mounting Direction: Straight)
	RSDG206B	U	P1		3	200	(Motor Mounting Direction: U, Controller: P1)

Actuator

Controller

Cable

Instruction Manual CD-ROM

**Components: Actuator, Controller, Cable**

**Accessory**

Controller I/O Specifications			
NPN/PNP	CC-Link	DeviceNet	
Instruction Manual (CD-ROM), Power Connector, Dummy Connector, 6 Mounting Nuts			
	CC-Link Connector	DeviceNet Connector	

**Robot Material / Surface Treatment**

Components	Body	Rod	Cover	Shaft	Ball Bushing
Material	Aluminum	Steel	ABS	Steel	Steel
Surface Treatment	Acrylic Paint				

**General Specifications**


Ball Screw	Motor	Position Detector	Operating Ambient Temperature, Humidity
Ø8 (C10 Rolled)	Stepping	Resolver (Incremental)	0~40°C, 35~85%RH (No Condensation)

Controller Specifications P.103~112

Standard Specifications FAQ P.110

Type	Lead (mm)	Positioning Repeatability (mm)	Max. Load Capacity (kg)		Max. Push Force (N)	Rated Running Life ①	Lost Motion (mm)	Rod Non-Rotational Accuracy (degrees)	Stroke (mm)	Max. Velocity ② (mm/sec)	Input Power Supply	Maximum Positioning Point
RSDG2	02	±0.02	Horizontal	Vertical	600	5,000 km or More	0.1 or Less	±0.05	50~300 (50 Pitch)	~80	DC24V ±10%	255 points
	06		45	24						~250		
	12		40	11						~500		

①. The service life in the vertical use may vary depending on the load capacity. Please refer to the "Service Life Table". ②. The maximum velocities may vary depending on the load capacity. Please refer to the "Velocity - Maximum Load Capacity Table."



Type	Part Number		Selection				
	① Lead (mm)	② With or w/o Brake (①)	③ Motor Mounting Direction	④ Controller (②)	⑤ I/O Module	⑥ Cable Length (m)	⑦ Stroke (mm)
RSDG2	02		Straight: Leave Blank Top Mounting: U	Point Control: C1 Pulse Control: P1 (DC24V ±10%)	NPN: N PNP: P CC-Link: C DeviceNet: D	1 3 5 10 (Flexible Cable)	50~300 (50mm Increment)
	06	W/o Brake: Leave blank With Brake: B					
	12						

① Choose the "With Brake" option for use in vertical applications. ② When the pulse train type controller is selected, the I/O type selection is not required.

Type	Dimensions / Mass	Motor Mounting Direction: Straight					Motor Mounting Direction: U						
		Stroke (mm)					Stroke (mm)						
		50	100	150	200	250	300	50	100	150	200	250	300
RSDG2	L1 (mm)	162.5	212.5	262.5	312.5	362.5	412.5	162.5	212.5	262.5	312.5	362.5	412.5
	L (mm)	270.5	320.5	370.5	420.5	470.5	520.5	209.5	259.5	309.5	359.5	409.5	459.5
	Mass (kg)(Note 6)	2.0	2.4	2.7	3.0	3.3	3.7	2.2	2.6	2.9	3.2	3.5	3.9



The brake adds 0.2 kg to the total mass.

**Note**

Power interruption circuit is not provided in this controller in order to provide maximum flexibility for customer specific safety scheme. Please be sure to provide an external power interruption circuit and form an emergency stop circuit. For Circuit examples see P.109.

**FAQ**

Q1. The actuator does not move.  
A1. When activating an actuator using Support Software or Handset Terminal, invalidate Option Parameter (No. 80). (Option Valid = I/O Terminal Valid, Option Invalid = I/O Terminal Invalid). Then turn the servo status "ON" and operate the homing procedure. After the completion of homing, start the operation by turning on "Operation".  
Q2. LED light is on. Is there a controller defect?  
A2. Blue: PWR (OFF: Control Power Shutoff, Blink: Servo OFF, ON: Servo ON), Red: ERR (OFF: Control Power Shutoff / No Error Alarm, Blink: Error Alarm On (External Factor), ON: Error Alarm On (Internal Factor))  
Q3. Teaching cannot be conducted by via I/O.  
A3. To conduct teaching via I/O, the status needs to be ON for MANUAL Input and OFF for Interlock Input. Note that it does not function in the state of "Homing Incomplete".  
Q4. Is low-speed operation possible?  
A4. Possible, however, 10 to 20% of max. velocity is the limit depending on the lead.



Days to Ship	Motor Mounting Direction: Straight	7 Days	Motor Mounting Direction: U	10 Days
--------------	------------------------------------	--------	-----------------------------	---------

Alterations	Part Number	Motor Mounting Direction	Controller Type	I/O Type	Cable Length	Stroke	(G, E...etc.)
	RSDG206B	U	C1	N	3	200	G-E

Alterations	Handset Terminal Standard Specification	Handset Terminal w/ Deadman's Switch Specifications	Support Software w/ USB Communication Cable	Support Software w/ D-Sub Communication Cable	I/O Cable	Cable for daisy-chain connection	Instruction Manual	Main Body Plastic Color Alterations	Actuator Mounting Foot Plate
Code	H	D	S	R	T/TP	C	ME5/KE3/KE4 KE4: Controller (P1) Details P.120	BC	HP
Spec.	Handset Terminal is included. Specifications P.109, 113	Handset Terminal w/ Deadman's Switch is included. Specifications P.109, 113	Support Software w/ USB Communication Cable is included. Specifications P.109, 113	Support Software w/ D-Sub Communication Cable is included. Specifications P.109, 113	I/O Cable is included. Required for NPN/PNP configurations. Specifications P.109, 113	A cable to connect multiple controllers. Up to 16 controllers can be connected. Specifications P.111 - 113	Operation Manual is included.	Change the actuator plastic parts color to black.	2 plates are included for horizontal mounting. Specifications P.113

For optional items, see P.113. It is more economical to order the optional items as alterations than purchasing them individually.  
Entering point data requires the handy terminal or the support software. An I/O Cable is required for Parallel Communication I/O Control.  
For details on daisy-chain, see P.111, 113. Please select the correct I/O cable type for the appropriate controller type.