

**PRC05P Connector Support Model Number Table**

Shape Specification	Number of Cores	CN1	Component Page	CN2	Component Page
P PT	2	PRC05-P2M	306		
	3	PRC05-P3M	306		
	5	PRC05-P5M	306		
	6	PRC05-P6M	306		
	8	PRC05-P8M	306		
	12	PRC05-P12M1	306		
S ST	2	PRC05-P2F	306		
	3	PRC05-P3F	306		
	5	PRC05-P5F	306		
	6	PRC05-P6F	306		
	8	PRC05-P8F	306		
	12	PRC05-P12F1	306		
PP	2	PRC05-P2M	306	PRC05-P2M	306
	3	PRC05-P3M	306	PRC05-P3M	306
	5	PRC05-P5M	306	PRC05-P5M	306
	6	PRC05-P6M	306	PRC05-P6M	306
	8	PRC05-P8M	306	PRC05-P8M	306
	12	PRC05-P12M1	306	PRC05-P12M1	306
SS	2	PRC05-P2F	306	PRC05-P2F	306
	3	PRC05-P3F	306	PRC05-P3F	306
	5	PRC05-P5F	306	PRC05-P5F	306
	6	PRC05-P6F	306	PRC05-P6F	306
	8	PRC05-P8F	306	PRC05-P8F	306
	12	PRC05-P12F1	306	PRC05-P12F1	306
PS	2	PRC05-P2M	306	PRC05-P2M	306
	3	PRC05-P3M	306	PRC05-P3M	306
	5	PRC05-P5M	306	PRC05-P5M	306
	6	PRC05-P6M	306	PRC05-P6M	306
	8	PRC05-P8M	306	PRC05-P8M	306
	12	PRC05-P12M1	306	PRC05-P12M1	306
PY	2	PRC05-P2M	306	F1.25-3.5	468
	3	PRC05-P3M	306	F1.25-3.5	468
	5	PRC05-P5M	306	F1.25-3.5	468
	6	PRC05-P6M	306	F1.25-3.5	468
	8	PRC05-P8M	306	F1.25-3.5	468
	12	PRC05-P12M1	306	F1.25-3.5	468
SY	2	PRC05-P2F	306	F1.25-3.5	468
	3	PRC05-P3F	306	F1.25-3.5	468
	5	PRC05-P5F	306	F1.25-3.5	468
	6	PRC05-P6F	306	F1.25-3.5	468
	8	PRC05-P8F	306	F1.25-3.5	468
	12	PRC05-P12F1	306	F1.25-3.5	468
RP RPT RPRT	2	PRC05-RB2M	307		
	3	PRC05-RB3M	307		
	5	PRC05-RB5M	307		
	6	PRC05-RB6M	307		
	8	PRC05-RB8M	307		
	12	PRC05-RB12M	307		
RS RST RSRT	2	PRC05-RB2F	307		
	3	PRC05-RB3F	307		
	5	PRC05-RB5F	307		
	6	PRC05-RB6F	307		
	8	PRC05-RB8F	307		
	12	PRC05-RB12F	307		

**PRC05J Connector Support Model Number Table**

Shape Specification	Number of Cores	CN1	Component Page	CN2	Component Page
JP JPT	2	PRC05-J2M	306		
	3	PRC05-J3M	306		
	5	PRC05-J5M	306		
	6	PRC05-J6M	306		
	8	PRC05-J8M	306		
	12	PRC05-J12F1	306		
JS JST	2	PRC05-J2F	306		
	3	PRC05-J3F	306		
	5	PRC05-J5F	306		
	6	PRC05-J6F	306		
	8	PRC05-J8F	306		
	12	PRC05-J12F1	306		
JPP	2	PRC05-J2M	306	PRC05-P2M	306
	3	PRC05-J3M	306	PRC05-P3M	306
	5	PRC05-J5M	306	PRC05-P5M	306
	6	PRC05-J6M	306	PRC05-P6M	306
	8	PRC05-J8M	306	PRC05-P8M	306
	12	PRC05-J12F1	306	PRC05-P12M1	306
JSS	2	PRC05-J2F	306	PRC05-P2F	306
	3	PRC05-J3F	306	PRC05-P3F	306
	5	PRC05-J5F	306	PRC05-P5F	306
	6	PRC05-J6F	306	PRC05-P6F	306
	8	PRC05-J8F	306	PRC05-P8F	306
	12	PRC05-J12F1	306	PRC05-P12F1	306
JPS	2	PRC05-J2M	306	PRC05-P2M	306
	3	PRC05-J3M	306	PRC05-P3M	306
	5	PRC05-J5M	306	PRC05-P5M	306
	6	PRC05-J6M	306	PRC05-P6M	306
	8	PRC05-J8M	306	PRC05-P8M	306
	12	PRC05-J12F1	306	PRC05-P12F1	306
JSP	2	PRC05-J2F	306	PRC05-P2M	306
	3	PRC05-J3F	306	PRC05-P3M	306
	5	PRC05-J5F	306	PRC05-P5M	306
	6	PRC05-J6F	306	PRC05-P6M	306
	8	PRC05-J8F	306	PRC05-P8M	306
	12	PRC05-J12F1	306	PRC05-P12M1	306
JPY	2	PRC05-J2M	306	F1.25-3.5	468
	3	PRC05-J3M	306	F1.25-3.5	468
	5	PRC05-J5M	306	F1.25-3.5	468
	6	PRC05-J6M	306	F1.25-3.5	468
	8	PRC05-J8M	306	F1.25-3.5	468
	12	PRC05-J12M1	306	F1.25-3.5	468
JSY	2	PRC05-J2F	306	F1.25-3.5	468
	3	PRC05-J3F	306	F1.25-3.5	468
	5	PRC05-J5F	306	F1.25-3.5	468
	6	PRC05-J6F	306	F1.25-3.5	468
	8	PRC05-J8F	306	F1.25-3.5	468
	12	PRC05-J12F1	306	F1.25-3.5	468
JP,JP	2	PRC05-J2M	306	PRC05-J2M	306
	3	PRC05-J3M	306	PRC05-J3M	306
	5	PRC05-J5M	306	PRC05-J5M	306
	6	PRC05-J6M	306	PRC05-J6M	306
	8	PRC05-J8M	306	PRC05-J8M	306
	12	PRC05-J12F1	306	PRC05-J12F1	306
JS,JS	2	PRC05-J2F	306	PRC05-J2F	306
	3	PRC05-J3F	306	PRC05-J3F	306
	5	PRC05-J5F	306	PRC05-J5F	306
	6	PRC05-J6F	306	PRC05-J6F	306
	8	PRC05-J8F	306	PRC05-J8F	306
	12	PRC05-J12F1	306	PRC05-J12F1	306
JP,JS	2	PRC05-J2M	306	PRC05-J2F	306
	3	PRC05-J3M	306	PRC05-J3F	306
	5	PRC05-J5M	306	PRC05-J5F	306
	6	PRC05-J6M	306	PRC05-J6F	306
	8	PRC05-J8M	306	PRC05-J8F	306
	12	PRC05-J12F1	306	PRC05-J12F1	306

- MS Connector Included Cable
- MS Connector Included Cable (Drip-proof)
- JL04 Connector Included Cable
- JL05 Connector Included Cable
- NCS Connector Included Cable
- NJC Connector Included Cable
- NJW Connector Included Cable
- NR Connector Included Cable
- NRW Connector Included Cable
- NET Connector Included Cable
- PRC04 Connector Included Cable
- PRC03 Connector Included Cable**
- PRC05 Connector Included Cable
- R03 Connector Included Cable
- R04 Connector Included Cable
- PLT Connector Included Cable
- HR10A Connector Included Cable
- XS2 Connector Included Cable
- DIN / Mini DIN Connector Included Cable