

R04 Connector Included Cable

Cables supporting more devices are available through the website!!

Connector Included Cable

R04P Connector Support Model Number Table

Stage Specification	Number of Cords	Model Number	CN1	Component Page	CN2	Component Page
PP	2	R04-PP-□-2	R04-P2M-4.8	259	R04-P2M-4.8	259
	3	R04-PP-□-3	R04-P3M-4.8	259	R04-P3M-4.8	259
	5	R04-PP-□-5	R04-P5M-4.8	259	R04-P5M-4.8	259
	6	R04-PP-□-6	R04-P6M-6.3	259	R04-P6M-6.3	259
	8	R04-PP-□-8	R04-P8M-6.3	259	R04-P8M-6.3	259
	8	R04-PP-F-8	R04-P8M-7.3	259	R04-P8M-7.3	259
12	R04-PP-□-12	R04-P12M-8.5	259	R04-P12M-8.5	259	
SS	2	R04-SS-□-2	R04-P2F-4.8	259	R04-P2F-4.8	259
	3	R04-SS-□-3	R04-P3F-4.8	259	R04-P3F-4.8	259
	5	R04-SS-□-5	R04-P5F-4.8	259	R04-P5F-4.8	259
	6	R04-SS-□-6	R04-P6F-6.3	259	R04-P6F-6.3	259
	8	R04-SS-□-8	R04-P8F-6.3	259	R04-P8F-6.3	259
	8	R04-SS-F-8	R04-P8F-7.3	259	R04-P8F-7.3	259
12	R04-SS-□-12	R04-P12F-8.5	259	R04-P12F-8.5	259	
PS	2	R04-PS-□-2	R04-P2M-4.8	259	R04-P2F-4.8	259
	3	R04-PS-□-3	R04-P3M-4.8	259	R04-P3F-4.8	259
	5	R04-PS-□-5	R04-P5M-4.8	259	R04-P5F-4.8	259
	6	R04-PS-□-6	R04-P6M-6.3	259	R04-P6F-6.3	259
	8	R04-PS-□-8	R04-P8M-6.3	259	R04-P8F-6.3	259
	8	R04-PS-F-8	R04-P8M-7.3	259	R04-P8F-7.3	259
12	R04-PS-□-12	R04-P12M-8.5	259	R04-P12F-8.5	259	
P	2	R04-P-□-2	R04-P2M-4.8	259		
	3	R04-P-□-3	R04-P3M-4.8	259		
	5	R04-P-□-5	R04-P5M-4.8	259		
	6	R04-P-□-6	R04-P6M-6.3	259		
	8	R04-P-□-8	R04-P8M-6.3	259		
	12	R04-P-□-12	R04-P12M-8.5	259		
S	2	R04-S-□-2	R04-P2F-4.8	259		
	3	R04-S-□-3	R04-P3F-4.8	259		
	5	R04-S-□-5	R04-P5F-4.8	259		
	6	R04-S-□-6	R04-P6F-6.3	259		
	8	R04-S-□-8	R04-P8F-6.3	259		
	8	R04-S-F-8	R04-P8F-7.3	259		
12	R04-S-□-12	R04-P12F-8.5	259			
PT	2	R04-PT-□-2	R04-P2M-4.8	259		
	3	R04-PT-□-3	R04-P3M-4.8	259		
	5	R04-PT-□-5	R04-P5M-4.8	259		
	6	R04-PT-□-6	R04-P6M-6.3	259		
	8	R04-PT-□-8	R04-P8M-6.3	259		
	8	R04-PT-F-8	R04-P8M-7.3	259		
12	R04-PT-□-12	R04-P12M-8.5	259			
ST	2	R04-ST-□-2	R04-P2F-4.8	259		
	3	R04-ST-□-3	R04-P3F-4.8	259		
	5	R04-ST-□-5	R04-P5F-4.8	259		
	6	R04-ST-□-6	R04-P6F-6.3	259		
	8	R04-ST-□-8	R04-P8F-6.3	259		
	8	R04-ST-F-8	R04-P8F-7.3	259		
12	R04-ST-□-12	R04-P12F-8.5	259			
PY	2	R04-PY-□-2	R04-P2M-4.8	259	F1.25-V3.5	468
	3	R04-PY-□-3	R04-P3M-4.8	259	F1.25-V3.5	468
	5	R04-PY-□-5	R04-P5M-4.8	259	F1.25-V3.5	468
	6	R04-PY-□-6	R04-P6M-6.3	259	F1.25-V3.5	468
	8	R04-PY-□-8	R04-P8M-6.3	259	F1.25-V3.5	468
	8	R04-PY-F-8	R04-P8M-7.3	259	F1.25-V3.5	468
12	R04-PY-□-12	R04-P12M-8.5	259	F1.25-V3.5	468	
SY	2	R04-SY-□-2	R04-P2F-4.8	259	F1.25-V3.5	468
	3	R04-SY-□-3	R04-P3F-4.8	259	F1.25-V3.7	468
	5	R04-SY-□-5	R04-P5F-4.8	259	F1.25-V3.9	468
	6	R04-SY-□-6	R04-P6F-6.3	259	F1.25-V3.11	468
	8	R04-SY-□-8	R04-P8F-6.3	259	F1.25-V3.13	468
	8	R04-SY-F-8	R04-P8F-7.3	259	F1.25-V3.14	468
12	R04-SY-□-12	R04-P12F-8.5	259	F1.25-V3.16	468	
RP	2	R04-RP-□-2	R04-R2M	260		
	3	R04-RP-□-3	R04-R3M	260		
	5	R04-RP-□-5	R04-R5M	260		
	6	R04-RP-□-6	R04-R6M	260		
	8	R04-RP-□-8	R04-R8M	260		
	12	R04-RP-□-12	R04-R12M	260		
RS	2	R04-RS-□-2	R04-R2F	260		
	3	R04-RS-□-3	R04-R3F	260		
	5	R04-RS-□-5	R04-R5F	260		
	6	R04-RS-□-6	R04-R6F	260		
	8	R04-RS-□-8	R04-R8F	260		
	12	R04-RS-□-12	R04-R12F	260		
RPT	2	R04-RPT-□-2	R04-R2M	260		
	3	R04-RPT-□-3	R04-R3M	260		
	5	R04-RPT-□-5	R04-R5M	260		
	6	R04-RPT-□-6	R04-R6M	260		
	8	R04-RPT-□-8	R04-R8M	260		
	12	R04-RPT-□-12	R04-R12M	260		
RST	2	R04-RST-□-2	R04-R2F	260		
	3	R04-RST-□-3	R04-R3F	260		
	5	R04-RST-□-5	R04-R5F	260		
	6	R04-RST-□-6	R04-R6F	260		
	8	R04-RST-□-8	R04-R8F	260		
	12	R04-RST-□-12	R04-R12F	260		
RPRT	2	R04-RPRT-□-2	R04-R2M	260		
	3	R04-RPRT-□-3	R04-R3M	260		
	5	R04-RPRT-□-5	R04-R5M	260		
	6	R04-RPRT-□-6	R04-R6M	260		
	8	R04-RPRT-□-8	R04-R8M	260		
	12	R04-RPRT-□-12	R04-R12M	260		
RPSRT	2	R04-RPSRT-□-2	R04-R2F	260		
	3	R04-RPSRT-□-3	R04-R3F	260		
	5	R04-RPSRT-□-5	R04-R5F	260		
	6	R04-RPSRT-□-6	R04-R6F	260		
	8	R04-RPSRT-□-8	R04-R8F	260		
	12	R04-RPSRT-□-12	R04-R12F	260		

R04J Connector Support Model Number Table

Stage Specification	Number of Cords	Model Number	CN1	Component Page	CN2	Component Page
JP	2	R04-JP-□-2	R04-J2M-4.8	259	R04-J2M-4.8	259
	3	R04-JP-□-3	R04-J3M-4.8	259	R04-J3M-4.8	259
	5	R04-JP-□-5	R04-J5M-4.8	259	R04-J5M-4.8	259
	6	R04-JP-□-6	R04-J6M-6.3	259	R04-J6M-6.3	259
	8	R04-JP-□-8	R04-J8M-6.3	259	R04-J8M-6.3	259
	8	R04-JP-F-8	R04-J8M-7.3	259	R04-J8M-7.3	259
12	R04-JP-□-12	R04-J12M-8.5	259	R04-J12M-8.5	259	
JS	2	R04-JS-□-2	R04-J2F-4.8	259	R04-J2F-4.8	259
	3	R04-JS-□-3	R04-J3F-4.8	259	R04-J3F-4.8	259
	5	R04-JS-□-5	R04-J5F-4.8	259	R04-J5F-4.8	259
	6	R04-JS-□-6	R04-J6F-6.3	259	R04-J6F-6.3	259
	8	R04-JS-□-8	R04-J8F-6.3	259	R04-J8F-6.3	259
	8	R04-JS-F-8	R04-J8F-7.3	259	R04-J8F-7.3	259
12	R04-JS-□-12	R04-J12F-8.5	259	R04-J12F-8.5	259	
JPSJ	2	R04-JPSJ-□-2	R04-J2M-4.8	259	R04-J2F-4.8	259
	3	R04-JPSJ-□-3	R04-J3M-4.8	259	R04-J3F-4.8	259
	5	R04-JPSJ-□-5	R04-J5M-4.8	259	R04-J5F-4.8	259
	6	R04-JPSJ-□-6	R04-J6M-6.3	259	R04-J6F-6.3	259
	8	R04-JPSJ-□-8	R04-J8M-6.3	259	R04-J8F-6.3	259
	8	R04-JPSJ-F-8	R04-J8M-7.3	259	R04-J8F-7.3	259
12	R04-JPSJ-□-12	R04-J12M-8.5	259	R04-J12F-8.5	259	
JP	2	R04-JP-□-2	R04-J2M-4.8	259		
	3	R04-JP-□-3	R04-J3M-4.8	259		
	5	R04-JP-□-5	R04-J5M-4.8	259		
	6	R04-JP-□-6	R04-J6M-6.3	259		
	8	R04-JP-□-8	R04-J8M-6.3	259		
	12	R04-JP-□-12	R04-J12M-8.5	259		
JS	2	R04-JS-□-2	R04-J2F-4.8	259		
	3	R04-JS-□-3	R04-J3F-4.8	259		
	5	R04-JS-□-5	R04-J5F-4.8	259		
	6	R04-JS-□-6	R04-J6F-6.3	259		
	8	R04-JS-□-8	R04-J8F-6.3	259		
	8	R04-JS-F-8	R04-J8F-7.3	259		
12	R04-JS-□-12	R04-J12F-8.5	259			
JPT	2	R04-JPT-□-2	R04-J2M-4.8	259		
	3	R04-JPT-□-3	R04-J3M-4.8	259		
	5	R04-JPT-□-5	R04-J5M-4.8	259		
	6	R04-JPT-□-6	R04-J6M-6.3	259		
	8	R04-JPT-□-8	R04-J8M-6.3	259		
	8	R04-JPT-F-8	R04-J8M-7.3	259		
12	R04-JPT-□-12	R04-J12M-8.5	259			
JST	2	R04-JST-□-2	R04-J2F-4.8	259		
	3	R04-JST-□-3	R04-J3F-4.8	259		
	5	R04-JST-□-5	R04-J5F-4.8	259		
	6	R04-JST-□-6	R04-J6F-6.3	259		
	8	R04-JST-□-8	R04-J8F-6.3	259		
	8	R04-JST-F-8	R04-J8F-7.3	259		
12	R04-JST-□-12	R04-J12F-8.5	259			
JPY	2	R04-JPY-□-2	R04-J2M-4.8	259	F1.25-V3.5	468
	3	R04-JPY-□-3	R04-J3M-4.8	259	F1.25-V3.5	468
	5	R04-JPY-□-5	R04-J5M-4.8	259	F1.25-V3.5	468
	6	R04-JPY-□-6	R04-J6M-6.3	259	F1.25-V3.5	468
	8	R04-JPY-□-8	R04-J8M-6.3	259	F1.25-V3.5	468
	8	R04-JPY-F-8	R04-J8M-7.3	259	F1.25-V3.5	468
12	R04-JPY-□-12	R04-J12M-8.5	259	F1.25-V3.5	468	
JSY	2	R04-JSY-□-2	R04-J2F-4.8	259	F1.25-V3.5	468
	3	R04-JSY-□-3	R04-J3F-4.8	259	F1.25-V3.7	468
	5	R04-JSY-□-5	R04-J5F-4.8	259	F1.25-V3.9	468
	6	R04-JSY-□-6	R04-J6F-6.3	259	F1.25-V3.11	468
	8	R04-JSY-□-8	R04-J8F-6.3	259	F1.25-V3.13	468
	8	R04-JSY-F-8	R04-J8F-7.3	259	F1.25-V3.14	468
12	R04-JSY-□-12	R04-J12F-8.5	259	F1.25-V3.16	468	
JPP	2	R04-JPP-□-2	R04-J2M-4.8	259	R04-P2M-4.8	259
	3	R04-JPP-□-3	R04-J3M-4.8	259	R04-P3M-4.8	259
	5	R04-JPP-□-5	R04-J5M-4.8	259	R04-P5M-4.8	259
	6	R04-JPP-□-6	R04-J6M-6.3	259	R04-P6M-6.3	259
	8	R04-JPP-□-8	R04-J8M-6.3	259	R04-P8M-6.3	259
	8	R04-JPP-F-8	R04-J8M-7.3	259	R04-P8M-7.3	259
12	R04-JPP-□-12	R04-J12M-8.5	259	R04-P12M-8.5	259	
JPS	2	R04-JPS-□-2	R04-J2F-4.8	259	R04-P2F-4.8	259
	3	R04-JPS-□-3	R04-J3F-4.8	259	R04-P3F-4.8	259
	5	R04-JPS-□-5	R04-J5F-4.8	259	R04-P5F-4.8	259
	6	R04-JPS-□-6	R04-J6F-6.3	259	R04-P6F-6.3	259
	8	R04-JPS-□-8	R04-J8F-6.3	259	R04-P8F-6.3	259
	8	R04-JPS-F-8	R04-J8F-7.3	259	R04-P8F-7.3	259
12	R04-JPS-□-12	R04-J12F-8.5	259	R04-P12F-8.5	259	
JSS	2	R04-JSS-□-2	R04-J2F-4.8	259	R04-P2F-4.8	259
	3	R04-JSS-□-3	R04-J3F-4.8	259	R04-P3F-4.8	259
	5	R04-JSS-□-5	R04-J5F-4.8	259	R04-P5F-4.8	259
	6	R04-JSS-□-6	R04-J6F-6.3	259	R04-P6F-6.3	259
	8	R04-JSS-□-8	R04-J8F-6.3	259	R04-P8F-6.3	259
	8	R04-JSS-F-8	R04-J8F-7.3	259	R04-P8F-7.3	259
12	R04-JSS-□-12	R04-J12F-8.5	259	R04-P12F-8.5	259	
JSP	2	R04-JSP-□-2	R04-J2F-4.8	259	R04-P2M-4.8	259
	3	R04-JSP-□-3	R04-J3F-4.8	259	R04-P3M-4.8	259
	5	R04-JSP-□-5	R04-J5F-4.8	259	R04-P5M-4.8	259
	6	R04-JSP-□-6	R04-J6F-6.3	259	R04-P6M-6.3	259
	8	R04-JSP-□-8	R04-J8F-6.3	259	R04-P8M-6.3	259
	8	R04-JSP-F-8	R04-J8F-7.3	259	R04-P8M-7.3	259
12	R04-JSP-□-12	R04-J12F-8.5	259	R04-P12M-8.5	259	

- MS Connector Included Cable
- MS Connector Included Cable (Drip-proof)
- JL04 Connector Included Cable
- JL05 Connector Included Cable
- NCS Connector Included Cable
- NJC Connector Included Cable
- NJW Connector Included Cable
- NR Connector Included Cable
- NRW Connector Included Cable
- NET Connector Included Cable
- PRC04 Connector Included Cable
- PRC03 Connector Included Cable
- PRC05 Connector Included Cable
- R03 Connector Included Cable
- R0