
## **GUIDE FOR COOLING COUPLERS**



Misumi

K3-JPSH

Misumi

F120-PM

F120-PF

SF120-PF

Misumi

SF120-HFLP

120-TPF

F120-TPF

Male screw

Male screw

Male scr

K3−□SH K4−□SH

Nitto

 $\Box P-M$ 

Fluoric rubber

 $\Box P-M$ 

(SUS)

(Fluoric rubber)

(Fluoric rubber)

□P (SUS)

(Fluoric rubber)

Nitto

HFL-□P-M

(Fluoric rubber)

 $HFL-\Box P$ 

HFI - P

(SUS)

(Fluoric rubber)

TPM

(Fluoric rubber)

TPM (SUS)

(Fluoric rubber)

(Fluoric rubber)

TPF (SUS)

(Fluoric rubber)

TPF

Misumi Nitto

Misumi

JPJH[

JPJ

LJPJ

LJPJH.

JPLJM\_

JPLJ 🗆